



ITEM NO.	PART NO.	DESCRIPTION	ITEM NO.	PART NO.	DESCRIPTION
1		Main Body (suits PT10N only)	25		Connecting Ring (suits PT20 & PT10N)
2		Lid Assembly (suits PT10N only)	26	PT20.26	O Ring (suits PT20 & PT10N)
3	PT10N.3	Liner	27	PT20.27	Centering Guide (suits PT20 & PT10N)
4	PT10N.4	Lid Gasket	28	PT20.28	Seal Ring (suits PT20 & PT10N)
5		Parts Guard (suits PT10N only)	29	PT20.29	Safety Valve Complete (suits PT20 & PT10N)
6		Hexagon Nut (suits PT20 & PT10N)	35		Material Outlet Cock 3/8" (suits PT20 & PT10N)
7	PT20.7	Release Cock (suits PT20 & PT10N)	36		Material Outlet Adapter (suits PT20 & PT10N)
8		O Ring (suits PT20 & PT10N)	37	PT20.37	Pressure Gauge (suits PT20 & PT10N)
9		Adapter (suits PT20 & PT10N)	38		Agitating Rod (suits PT10N only)
10		Air Inlet Adapter (suits PT20 & PT10N)	39		Hexagon Nut (suits PT20 & PT10N)
10-1		Air Adapter (suits PT20 & PT10N)	40	PT20.40	Agitating Propeller (suits PT20 & PT10N)
11		Branch Tee (suits PT20 & PT10N)	41		Swing Bolt (suits PT20 & PT10N)
12		Air Outlet Cock (suits PT20 & PT10N)	42		Washer (suits PT20 & PT10N)
13		Nut (suits PT20 & PT10N)	43		Thumb Nut (suits PT10N only)
14		Air Outlet (suits PT20 & PT10N)	45		Moving Wheel (suits PT20 & PT10N)
15		Air Inlet Cock 1/4" (suits PT20 & PT10N)	46		C Snap Ring (suits PT20 & PT10N)
16	PT20.16	Pressure Regulator (suits PT20 & PT10N)	47		Cotter (suits PT20 & PT10N)
17		Handle Bolt (suits PT20 & PT10N)	48		Fluid Tube (suits PT10N only)
18		Handle Bar (suits PT20 & PT10N)	49	PT20.49/S	Filter Housing (78mm Nylon/50mm Metal)
19		Nut for Handle (suits PT20 & PT10N)	50	PT20.50/S	Filter Base (78mm Nylon/50mm Metal)
20		Handle (suits PT20 & PT10N)	51	PT20.51/S	Filter (78mm Nylon/50mm Metal)
21		Screw for Handle (suits PT20 & PT10N)	52	PT20.52/S	Snap Ring (78mm Nylon/50mm Metal)
22		Screw Bolt (2) (suits PT20 & PT10N)	53		Air Flow Guider (suits PT20 & PT10N)
23		Cap Screw (suits PT20 & PT10N)	54		
24		O Ring for Cap Screw (suits PT20 & PT10N)			

Updated: Nov 2024