



draw

ITEM NO.	PART NO.	DESCRIPTION	ITEM NO.	PART NO.	DESCRIPTION
1		Main Body	25		Connecting Ring
2		Lid Assembly	26	PT20.26	O Ring
3	PT20.3	Liner	27		Centring Guide
4	PT20.4	Lid Gasket	28	PT20.28	Seal Ring
5		Parts Guard	29	PT20.29	Safety Valve Complete
6		Hexagon Nut	35		Material Outlet Cock
7	PT20.7	Release Cock	36		Material Outlet Adapter
8		O Ring	37	PT20.37	Pressure Gauge
9		Adapter	38		Agitating Rod
10		Air Inlet Adapter	39		Hexagon Nut
10-1		Air Adapter	40		Agitating Propeller
11		Branch Tee	41		Swing Bolt
12		Air Outlet Cock	42		Washer
13		Nut	43		Thumb Nut
14		Air Outlet	45		Moving Wheel
15		Air Inlet Cock	46		C Snap Ring
16	PT20.16	Pressure Regulator	47		Cotter
17		Handle Bolt	48		Fluid Tube
18		Handle Bar	49	PT20.49	Filter Housing
19		Nut for Handle/ Wheel	50	PT20.50	Filter Base
20		Swing Rocker	51	PT20.51	Filter
21		Screw for Handle	52	PT20.52	Snap Ring
22		Screw Bolt (2)	53		Spanner
23		Cap Screw	54		Air Flow Guider
24		O Ring for Cap Screw			

Updated: March 2021